




Last Loaf Pusher Safety Kit



Part #57009 Last Loaf Safety Pusher Kit

Avoid broken infeed flights and unnecessary down-time!

Operation of the infeed conveyor is stopped when the last loaf pusher is removed from its storage position.

The conveyor will only start operating when the conveyor start button is depressed. The slicer returns to normal operation when the pusher is returned to its home position.

The Last Loaf Pusher Safety Kit comes complete with all necessary components, hardware, wiring, installation instructions and diagrams.

We are s/l/i/c/e/d bread!



Bettendorf Stanford, Inc.

PO Box 790 Salem, IL 62881 Ph:800-548-2253 Ph:618-548-3555 Fax 618-548-3557

e-mail: sales@bettendorfstanford.com

Website: www.bettendorfstanford.com